

<b>THROTTLE CASING</b>	1
- Removing/Refitting	1
- Flow meter - Removing/Refitting	2
<b>ACCELERATOR POTENTIOMETER</b>	3
- Removing/Refitting	3
<b>CENTRE LAMBDA SENSOR</b>	4
- Removing/Refitting	4
<b>FRONT RIGHT OR LEFT LAMBDA SENSOR</b>	5
- Removing/Refitting	5
<b>EXHAUST MANIFOLD</b>	6
- Removing/Refitting	6
<b>CATALYTIC PRE-CONVERTER</b>	8
- Removing/Refitting	8